

Hi. I bought a Rotatone a few months ago and finally found the courage to install it on my wife's Ericsson Dialog telephone (DLG 0147), made in Brazil, probably in the early 80s.

Took me a whole day to figure it out but here's how I got it to work:

1. Dial wires: disconnected the blue wire from terminal 14 and the white wire from terminal 10. Left red untouched on 15.
2. Rotatone Orange+Red -> Phone terminal 3 or 4 (both were connected to my phone line's positive), along with original wires
3. Rotatone Blue -> Phone terminal 14 (connected to earth, disconnects when the phone's hung up)
4. Rotatone White -> Dial's blue wire
5. Rotatone Orange -> Terminal 15 (along with original red wire coming from Dial)
6. Rotatone Brown -> Dial's white wire

Notice: I left the Dial's red wire untouched because without it on 15 and blue on 14, the tension between + and - would come up to 90v instead of the usual 15v.

I can now get the phone to dial, save & load speed dials. I don't know if color schemes will be the same throughout the world, but I'd be honoured if you made these directions available on your website somehow.

Thank you for such a nice product.

Daniel Araujo
<http://www.dan.mus.br/>
Brasilia, Brazil

PS: Here's our phone ringing:
http://www.youtube.com/watch?v=ffmO_nWLLhA