



ROTATONE modification to GPO Type 746

1. Remove Dial Loom. Clean Dial Contacts. Connect Brown, White, Orange wires from Rotatone to dial
2. Remove Links from T16 to T17, T6 to T7 and T5 to T6
3. Place Link from T17 to T18
4. Solder wire to point 4 on IC/point 4 on hook switch and solder to underside of T14
5. Connect Bridge Rectifier, Zener Diode and remaining leads of Rotatone as diagram above
6. If polarity protection is not required and bridge omitted, link T15 to T17 and link T5 to T13
7. For 2-wire operation link T8 to T16 and link T7 to T15